


# **Complete the Initial Sample Test Report (EMPB)** form

Download and open the file from the website.

**Number of test parts**: Select a minimum of 10 parts for an initial sample test report. **Number of samples**: As, for example in the case of screws, destructive tests also need to be carried out, in these cases more samples should accordingly be made available. All the inspection characteristics can be found on the drawing or on the product data sheet.



### **Complete the cover sheet:**


Select the "Deckblatt-Cover Sheet" table.

Deckblatt-	-Cover Sheet	PB Übersicht-Rep	ort Overview	/ PB Einzelwerte-Rep	oort Values 📝 Z	eichnung-Drawing 🦯	Information / Katal	og-Catalogue			
Fixing	syster	ns	1	ischer innovative		Final result:					
Tes	st report	english for	ć	article descripti	on	fischer article	no.				
Supplier: Address:		Customer: Address:	fischerwerke Gmbl- Klaus-Fischer-Stra 72178 Waldachtal-	aße 1	Sampling reaso  First-Off Re-samplin	ng					
Order-/pro	ioot no		Distribution list			Product modification Production relocation					
(Raw) Mate	•		Dept.:	Name:			on of the production	on process			
Date of del			Бери	ivaine.			erruption the producti	•			
Number sa						New sub-s					
Number te							Measure capture				
Drawing no	D.										
Drawing in	dex/date					Attachment	''				
Status in S	AP-PLM										
Toolnumbe	er					Report Ov	erview				
Subjectnur	mber					Report Val	ues				
Sampletes	t supplier					Drawing					
						Materialtes					
						Product da					
	on supplier	(only extern)	Confirmation customer				ocess qualificatio				
Name:			Name:				st equipment qua	lification			
Dept.:			Dept.:			Others (Inf	formation,)				
Phone:			Phone:								
E-mail:			E-mail:			Remarks					
Date:			Date:								
Signature mandatory f	fiold		Signature								



#### Complete the PB overview:

Select the "PB Übersicht-Report Overview" table.



- "Cat no." column: Enter here the number of the desired inspection characteristics from the catalogue (in the right-hand column). The "inspection characteristics" field will then be filled in automatically.
- "Specified value" column: The minimum and maximum dimensions are entered here. If there is only a minimum dimension, this is entered in the "Min." column, and an "x" must be entered in the "Max." column. If only a maximum dimension is present, the value is entered in the "Max." column, the "Min." column can remain empty.
- "Format" column: The text in the "Remarks" column can be formatted here.
- "to be tested" column: The dimensions marked in the drawing as the main inspection characteristics can also be indicated here.
- "Inspection characteristics", "Test equipment" and "Abr." columns:

Here you have the option of defining yourself the inspection characteristics and the associated test equipment, if these are not present in the catalogue (see below)



## Complete the PB individual values:

Select the "PB Einzelwerte-Report Values" tables.

M 4 P M Deckblatt-Cover Sheet / PB Übersicht-Report Overview PB Einzelwerte-Report Values / Zeichnung-Drawing / Information / Katalog-Catalogue / fischer 🗪 Fixing systems Test report english for article description fischer article no. Drawing no Drawing index/date Order-/project no. Cat | Test | Specified value Ist-Werte inspection characteristics No. 01 02 03 no. equip. Min. 10 Max. Xbar 4 OK OK OK OK Remarks

"Test equipment" column: is filled in automatically, but can also be overwritten.

If your test equipment is not present in the list, please follow these steps:

- Define a 3-digit abbreviation for your test equipment and enter it in column D.
- Please provide a brief explanation in the "Remarks" rows


"Ist-Werte" (current values): The measured dimensions are entered here. For attributive characteristics, "OK" and "not OK" can be entered in the "Ist-Werte" column. With "OK" the number of results entered must match the number in the "Number tested" field. Then an "OK" appears in the PB overview in the "Result" column. If one or several "not OK" values are entered, a "not OK" appears automatically in the result. The "Min." and "Max." specified value fields must either be empty or respectively contain the same values, for example, the ST characteristic. This must be included under both "Min." and "Max.".

	•			*							
inspection characteristics		Cat	Remarks	Basic-	Basic- Specified value		Ist-Werte		Result		
No.	H = characteristic in drawing subject to test	no.	(Specified text)	size	Min.		Max.	Min.		Max.	Result
01	Embossing	088		ST	ST	-	ST	OK	-	OK	OK



## **Complete the drawing:**

Select the "Zeichnung-Drawing" table.



The drawing can be inserted here, e.g. in pdf format.

Select cell A1 and insert the drawing.

Select the drawing and press the right mouse button.

Sequence → In the background.

"Only Testdrawing" is placed in a free area in the drawing.

Depending on the number of test characteristics, copy the arrows, give them numbers, and place the arrows on the corresponding inspection characteristics.

#### **Complete the information:**

Select the "Information" table.

20						
H + P + H	Deckblatt-Cover sheet	PB Übersicht-Report Overview	PB Einzelwerte-Report Values	Zeichnung-Drawing	Information /	Katalog-Catalogue

Additional information may be placed here, e.g. images.

Additional tables, for example for images, information, etc. can also be generated.

Version	Version control	Changed by:	Date:	Approved by:	Date:
0	Creation of work instruction for Initial Sample Test externally	Thomas Keller	09/05/2017	Häßler / Appich	16/05/2017
1	Expanded for the new functions "inspection characteristics" and "test equipment"	Steffi Häßler	14/07/2017	Achim Appich	14/07/2017
2					